

Open Faced Decal Application Instructions

****Patience and care are required for proper application, and if instructions are followed completely your decal will adhere as advertised. We only use Oracal 3.2Mil Films. We are not held responsible for application errors, but will supply replacement decals at a discounted price.**

****Remember****

- Wash your hands before applying the decal.
- If it is cold outside the decal will not adhere, and will become brittle. If it is hot outside the decal may stretch.

1. Clean the area thoroughly with soft bristle toothbrush, dish soap and water. Be sure to do this in a location free of dirt and wind. Allow the area to dry completely.

CLEAN IT TWICE IF YOU HAVE ANY TYPE OF ARMORAL OR GREASY SUBSTANCE.

2. *****This is the step where most application errors will occur.**
Peel the letters away from the backing. You should use a precision knife with a sharp point. Be sure to lift all areas/edges of the letter before pulling away from the backing paper so that the decal will not tear. Align the letter over the appropriate letter and lightly press. Once you feel you have the decal in the proper position PRESS DOWN on it to ensure the sticky side has adhered.

Leave a positive feedback, email us a picture of your new amazing decal and enjoy!